




# Sign Insertion Instructions




1. Slide sign down through the tabs



2. Slide through, pulling sign in front of bottom slot until sign hits the ground



3. Push sign up into top slot




4. Slide sign down into bottom slot

# Sand Filling Instructions

The Signicade Deluxe has four fill holes for sand, two on each side of the sign stand.

Remove plug from fill hole and fill with sand. 2.5 lbs. of sand per hole for a total 10 lbs. per sign frame is recommended.

Dry sand is suggested for ease of filling.



Sand Fill Holes

